

RT112 Office Cradle



Quick Start Guide

V1.3

▶ Product View



Power LED



USB-C Display Port

USB Port

Ethernet Connector

USB-C Charging Port

▶ Package

Please make sure the following contents are in the RT112 office cradle gift box.
If something is missing or damaged, please contact your Unitech representative.

▶ The Package Contents

- RT112 Office Cradle

▶ Optional Accessories

- Cradle Hook

▶ Getting Started

To charge the RT112, please follow these steps:

1. Ensure the cradle is powered on.
2. Place the RT112 in the cradle until it locks in place.

▶ Set Up and Charge the RT112

Insert the RT112 into the slot on the RT112 office cradle, ensuring it locks securely into place.



▶ Set Up the Display Port

1. Connect the power adapter and Type-C to HDMI to the RT112 office cradle first.



2. Insert the RT112 into the slot on the RT112 office cradle, ensuring it locks securely into place. If it can not work without following instruction, just re-plug RT112 main unit to the office cradle will be fine.



▶ LED Indicator Status

RT112 Power



Power LED

Power LED

LED Status	Description
Blue LED	Cradle power on
LED Off	Cradle power off

The Ethernet connector will display a green light when it is successfully connected.

Note: The power status of the RT112 is on itself.

▶ Charging the RT112

We highly recommend using the adapter provided in the RT112 package. If you use a different adapter, please ensure that you follow the guidelines below before charging:

- a. Use a PD fast charging adapter
- b. Recommended to use 45W adapter (or 45W above)
- c. Support 12V/3A segment charging

1. Insert one end of the USB-C cable into the charging port next to the Ethernet connector on the office cradle, and plug the other end into a socket.
2. Please ensure the RT112 is installed securely and properly. When it is successfully connected, the cradle will begin fast charging using the cradle's pogo pin.



WARNING!

There is a risk of fire and burns if the cradle is used improperly. **DO NOT** disassemble, crush, puncture, short external contacts, or dispose the cradle in fire or water.

CAUTION!

To ensure the unit working properly, please keep all connectors away from the contaminants such as dust, grease, mud, and water. Negligence may cause the unit to lose communication, short circuit, or overheated. If the connector is damaged, please ensure the connector is fully repaired before using the unit to avoid short circuiting.

DO charge between 20% and 80% to protect your battery.

Avoid full discharges (<0%) or charging all the time (always 100%) to reduce stress on the battery.

▶ Set Up the Cradle Hook

1. Please remove the soft pads from the four corners of the bottom of the RT112 Office Cradle first.



2. Use a screwdriver to fasten the cradle hook on both sides of the RT112 Office Cradle.



EU Importer:

Unique Technology Europe B.V.
Kapitein Hatterasstraat 19, 5015 BB, Tilburg, the
Netherlands

Copyright 2024 Unitech Electronics Co., Ltd. All rights reserved.
Unitech is a registered trademark of Unitech Electronics Co., Ltd.



<http://www.ute.com/>